



# CC6100M-CZK

9 Combinations

	Tube-A	Tube-B	Tube-C	Tube-D	Tube-E	Tube-F
Mode 1	50 Kč	50 Kč	10 Kč	5 Kč	2 Kč	1 Kč
Mode 2	50 Kč	50 Kč	10 Kč	5 Kč	1 Kč	1 Kč
Mode 3	50 Kč	50 Kč	10 Kč	5 Kč	2 Kč	2 Kč
Mode 4	50 Kč	50 Kč	5 Kč	5 Kč	2 Kč	1 Kč
Mode 5	50 Kč	50 Kč	5 Kč	5 Kč	1 Kč	1 Kč
Mode 6	50 Kč	50 Kč	5 Kč	5 Kč	2 Kč	2 Kč
Mode 7	50 Kč	50 Kč	10 Kč	10 Kč	2 Kč	1 Kč
Mode 8	50 Kč	50 Kč	10 Kč	10 Kč	1 Kč	1 Kč
Mode 9	50 Kč	50 Kč	10 Kč	10 Kč	2 Kč	2 Kč