



CC6100M-EUR

24 Combinations

	Tube-A	Tube-B	Tube-C	Tube-D	Tube-E	Tube-F
Mode 1	€ 1	€ 1	€ 1	10 ¢	10 ¢	10 ¢
Mode 2	€ 1	€ 1	€ 1	10 ¢	10 ¢	5 ¢
Mode 3	€ 1	€ 1	€ 1	10 ¢	5 ¢	5 ¢
Mode 4	€ 1	€ 1	€ 1	5 ¢	5 ¢	5 ¢
Mode 5	€ 1	€ 1	20 ¢	10 ¢	10 ¢	10 ¢
Mode 6	€ 1	€ 1	20 ¢	10 ¢	10 ¢	5 ¢
Mode 7	€ 1	€ 1	20 ¢	10 ¢	5 ¢	5 ¢
Mode 8	€ 1	€ 1	20 ¢	5 ¢	5 ¢	5 ¢
Mode 9	€ 1	50 ¢	€ 1	10 ¢	10 ¢	10 ¢
Mode 10	€ 1	50 ¢	€ 1	10 ¢	10 ¢	5 ¢
Mode 11	€ 1	50 ¢	€ 1	10 ¢	5 ¢	5 ¢
Mode 12	€ 1	50 ¢	€ 1	5 ¢	5 ¢	5 ¢
Mode 13	€ 1	50 ¢	20 ¢	10 ¢	10 ¢	10 ¢
Mode 14	€ 1	50 ¢	20 ¢	10 ¢	10 ¢	5 ¢
Mode 15	€ 1	50 ¢	20 ¢	10 ¢	5 ¢	5 ¢
Mode 16	€ 1	50 ¢	20 ¢	5 ¢	5 ¢	5 ¢
Mode 17	50 ¢	50 ¢	€ 1	10 ¢	10 ¢	10 ¢
Mode 18	50 ¢	50 ¢	€ 1	10 ¢	10 ¢	5 ¢
Mode 19	50 ¢	50 ¢	€ 1	10 ¢	5 ¢	5 ¢
Mode 20	50 ¢	50 ¢	€ 1	5 ¢	5 ¢	5 ¢
Mode 21	50 ¢	50 ¢	20 ¢	10 ¢	10 ¢	10 ¢
Mode 22	50 ¢	50 ¢	20 ¢	10 ¢	10 ¢	5 ¢
Mode 23	50 ¢	50 ¢	20 ¢	10 ¢	5 ¢	5 ¢
Mode 24	50 ¢	50 ¢	20 ¢	5 ¢	5 ¢	5 ¢